

**primary electrons (pe) (in *in situ* microanalysis)**

Electrons generated by a thermal or field emission source used to bombard the specimen for generation of the analytical signals.

1983, 55, 2026