

**vaporization temperature (in electrothermal atomization),  $T_{\text{vap}}$**

The temperature of the atomization surface at which analyte loss becomes statistically significant.

1992, 64, 257