

zero point of scale (of a balance)

The *rest point* of the properly adjusted balance with no load on the pans and the rider (or chain) in the zero position.

O.B. 36